

LED Light and Timer Operation

#ISZ-STP-LED

The LED light on this aquarium has 4 different timer settings that you can set that will shut your LED off after 1hr, 2hr, 4hr or 8hr long durations. Please follow the below instructions on how to activate the setting you have chosen. Please note: the LED stays on unless (A) one of the timer settings is activated or (B) the LED is turned off manually or (C) you unplug the power source. All LED functions are controlled by the Blue Button on top of the hood.

General LED Operation

1. To select the preferred color LED press the blue button down for 1 second. Each consecutive press of the button changes color or transition settings. There are 7 color selections along with 4 transitioning and color combinations plus an off selection.
2. To manually **turn off** the LED hold the blue button down for 1.2+ seconds. The LED will **turn off** no matter what the current color or timers are set to.

Timer Settings

1. After you have turned the LED on, hold the blue button down for 3+ seconds, the LED will blink Red 1 time. The 1hr timer setting is now set. The LED will now shut off in 1 hour from the time you turn the LED on. Remember, after setting a timer, each time you turn the LED on it will stay on for your chosen timer duration.
2. Holding the blue button down again for 3+ seconds the LED will blink Blue twice. The LED will now shut off in 2 hours from the time you turn the LED on.
3. Holding the blue button down again for 3+ seconds the LED will blink Green 3 times. The LED will now shut off in 4 hours from the time you turn the LED on.
4. Yes, holding the blue button down again for 3+ seconds the LED will blink White 4 times. The LED will now shut off in 8 hours from the time you turn the LED on.

NOTE: To clear out all timer settings it is easiest to unplug the power supply from the top of the hood.

**IF THIS COMPONENT DOES NOT
FUNCTION PROPERLY OR YOU ARE
UNSURE OF IT'S OPERATION**

DO NOT RETURN TO THE STORE

CALL (800)-545-1344

FOR HELP OR COMMENTS CALL (800) 545-1344

OR GO ONLINE TO

www.kollerproducts.com